



N° Object	Code	Description	Qty
129	601154	Timer	1
1014	ZS2026	Thermostat TY60 N.O. fixing B	1
1441	ZS2665	Support for fan timelag device	1
1957	ZS3495	Washer 4.3 x 10 x 3	4
1996	ZS3171	Blocking plate hob-side Party	2
3717	ZS6026	Switch for induction encoder	5
4210	ZS5377	Energy regulator for induction 230 V EGO EU	5
4211	ZS5378	Induction 5 element EGO	1
4266	ZS6787	Encoders control board	1
4522	ZS7089	Knob gas burners ATG	6
4673	GR7383	Assembly cooktop cooker 100 double oven induction Prt/Drb	1
4321	ZS6726	Glass for 100 induction hob or cooker	1
4714	ZS6821	Support for electronic control induction element	1
4749	ZS7384	Support bar for induction element rear cooker 100	1
4750	ZS7385	Support bar for induction element front cooker 100	1
4868	ZS7663	Clamp support for induction 100 Party lateral	2
5535	GP0056	Assembly control panel front 6 zone electric oven ENF 100 S.Steel serygr.	1
5801	ZS8317	Display support	1
5753	ZP0068	Thickness for profile	2
5765	ZP0085	Commutator support 3 positions	2
5783	ZS6817	Feet for electronic components EGO	3
5784	ZS6904	Cover for induction terminal board	1
5785	ZS6905	Bridge for induction terminal board	1
5853	ZS8919	Frontal bar profile cooker 100	1




N° Object	Code	Description	Qty
94	481814	Commutator multif. for 90 built-in oven(no pizza)	1
107	482120	Thermostat cooker 192	1
455	ZS1075	Oven thermostat	1
538	ZS1204	Led transparent	3
539	ZS1205	Fluorescent green warning light	1
823	ZS1755	Fluorescent orange warning light	2
1588	ZS2889	Commutator oven functions 90 EGO	1
3217	ZS4568	Small and grilling oven switch	1
3649	ZS5713	Electrical display support	1
3921	ZS6051	Glass lcd 3 button no holes	1
3936	ZS6334	Timer (blue led) 3 TT SIEBE Touch meat probe	1
4522	ZS7089	Knob gas burners ATG	3
5765	ZP0085	Commutator support 3 positions	1



N° Object	Code	Description	Qty
98	481913	Terminal board for oven 32 PA 233	1
1316	ZS2474	Front central muffle support cooker 100/120 double oven	1
1439	ZS2663	Cooling fan L=180 Plaset (AU)	1
1944	ZS2719	Air conveyor for cooktop 090/100 Prb/Drb	1
3030	ZS3312	Blocking plate hob-side Party	2
3054	ZS5128	Ramp hole closing plate	1
3102	ZS2749	Muffle fan guard cooker 100 double oven Prt / Drb	1
3484	ZS5647	"Steel - Stile in cucina" plate	1
5030	ZS7491	hinge support 100 Prt/ Drb	2
5033	ZS7657	Door hinge for drawer door	2
5266	ZS8337	Side external right/left higher ADG S.STEEL	2
5272	ZS8346	Rear support for muffle left/right side cooker 100 double oven	2
5273	ZS8347	Upper guard for drawer 100	1
5274	ZS8348	Front support for muffle Right side 100 double oven cooker	1
5275	ZS8349	Rear guard for cooker 100 double oven Prt / Drb	1
5277	ZS8361	Rear support for muffle left/right side cooker 100 double oven	1
5278	ZS8362	Front support for muffle Left side 100 double oven cooker	1
5311	ZS8459	Drawer door cooker 100 ADG s.steel	1
5312	ZS8460	Counterdoor drawer cooker 100	1
5559	ZA0059	Adjustable feet H100/145 inox ADG	4
5874	GR2746	Assembly complete lower reinforcement 100	1
130	601156	Tapping screw M10 galvanized	4
3100	ZS2746	Lower guard for cooker 100 double oven Party	1

4387


1334



2937



1383



1277



2943



1277



2938



2944




4473




N° Object	Code	Description	Qty
4387	GR7024	Assembly glued oven door 60/100 double oven	1
2937	GR4313	Assembly door 30/60/90 right bar profile 07	1
2938	GR4314	Assembly door 30/60/90 left bar profile 07	1
1334	ZS2308	Inner glass oven door 60	1
1277	ZS2414	Door hinge for oven 60 G	2
1383	ZS2550	Glued external oven door 60/100 double oven	1
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1
4473	ZS6995	Door oven handle for oven 60 PLG	1






N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
82	481403	Thermoswitch 16 Ampere	1	4115	ZS6631	Complete Lamp-holder for oven (max 25 W)	1
89	481727	Circular tangential oven 90 fan (AU) with fan and nut	1	4132	ZS6541	Gasket oven 60 H=8.9 mat HT	1
128	601152	Spring fixing feeler for built-in oven	2	4574	ZS6005	Fixing support for turnspit motor oven 60/90	1
566	ZS7590	Lower heating element for oven 60 (1200W/230V)	1				
1209	414559	Lateral frame support for built-in oven	6				
1217	ZS2283	Oven lateral frame 30/60/90	2				
1219	ZS2286	Chromed wire grid for oven 60	1				
1225	ZS2312	Side muffle oven 30/60/90 enamelled 04	2				
1230	ZS2322	Enamelled muffle ceiling oven 60	1				
1231	ZS2324	Enamelled muffle bottom for oven 60	1				
1232	GR2326	Assembly rear muffle oven 60/100 enamelled 04	1				
1401	ZS2585	Tapping screw M5 aluminium	4				
1233	ZS2328	Enamelled muffle front side oven 60	1				
1248	ZS2364	Enamelled drip tray for oven 60	1				
1260	ZS2395	Hinge support 06	2				
1305	ZS2456	Lower heating elem.support oven 60 double oven 04	1				
1306	ZS2459	Lower heating element tray oven 60 04	1				
1325	ZS2496	Grill heating element support for muffle oven 60 enamelled 04	1				
1333	ZS2289	Support for grillrod 60/90	1				
1346	ZS2484	Fan cover for oven 60 with turnspit hole BLACK	1				
1349	ZS2499	Fixing support for turnspit motor oven 60/90	1				
1424	ZS2629	White glass wool for rear side 60 oven 04	1				
1425	ZS2632	White glass wool for 60 oven 04	1				
1467	ZS2604	Support for safety thermostat 04	1				
1832	482094	Grill heating element for oven 60 (1900+850W)	1				
2891	482589	Circular heating element 230V-2100W	1				
3259	ZS5174	Turnspit for oven 60 (4 forks + handle) - 04	1				
3261	ZS5236	Turnspit motor reducer 50/60 Hz	1				



N° Object	Code	Description	Qty
4385	GR7022	Assembly glued oven door 30	1
2937	GR4313	Assembly door 30/60/90 right bar profile 07	1
2938	GR4314	Assembly door 30/60/90 left bar profile 07	1
1224	ZS2311	Inner glass oven door 30	1
1276	ZS2413	Door hinge for oven 30	2
1381	ZS2546	Glued external oven door 30 KL	1
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1
4472	ZS6994	Door oven handle for oven 30 PLG	1



N° Object	Code	Description	Qty
82	481403	Thermoswitch 16 Ampere	1
103	482072	Upper heating element cooker Ratio	1
123	541011	Spacer washer for built-in oven	2
128	601152	Spring fixing feeler for built-in oven	2
188	ZS7653	Lower heating element for oven 30	1
1209	414559	Lateral frame support for built-in oven	6
1217	ZS2283	Oven lateral frame 30/60/90	2
1220	ZS2287	Chromed wire grid for oven 30	1
1225	ZS2312	Side muffle oven 30/60/90 enamelled 04	2
1226	ZS2314	Enamelled muffle ceiling oven 30	1
1227	ZS2316	Enamelled muffle bottom for oven 30	1
1228	ZS2318	Muffle rear side oven 30 enamelled 04	1
1229	ZS2320	Enamelled muffle front side oven 30	1
1247	ZS2362	Enamelled drip tray for oven 30	1
1260	ZS2395	Hinge support 06	2
1303	ZS2454	Lower heating elem.support oven 30 04	1
1304	ZS2455	Lower heating element tray oven 30 04	1
1324	ZS2494	Grill heating element support for muffle oven 30 enamelled 04	1
1413	ZS2599	Gasket oven 30 04	1
1422	ZS2627	White glass wool for rear side 30 oven 04	1
1423	ZS2628	White glass wool for 30 oven 04	1
1467	ZS2604	Support for safety thermostat 04	1
4115	ZS6631	Compete Lamp-holder for oven (max 25 W)	1
5932	ZP0119	Turnspit hole cap	1

N° Object	Code	Description	Qty
131	BS0296	Adhesive tape 4959	600
132	ZS5148	Adhesive tape 16,5 m x 19h (3M)	120
711	ZS1929	Faston	1
725	601108	Anti-overturning device	0,3
1210	ZS5149	Adhesive tape 33 mt x 17h mm x th 0,6 mm (3M 4930)	200
1329	ZS5150	Adhesive tape 33 mt x 25h mm x Th 1.55 mm (3M)	10000
1586	ZS2770	Additional wiring generic L=60 cm Fem Fem	2
4761	ZS7454	Wiring diagram for cooker D10FF-6I Drb	1
5793	ZS7811	Instruction booklet cooker Party MULTILANGUAGE	1