





Piano genesi GQ9-4T SS OT Steel G20/20 230/50 EU

CLIENTE

Code	Description	Qty	Code	Description	Qty
ZA0878	Aluminium adhesive badge "Steel tricolore"	1			
ZA1096	Cable clamp	1			
ZA1699	Terminal block for appliance UL	1			
ZC0584	Control panel front 4 burners B/T Genesi 90 S.Steel with serygr.	1			
ZP0404	Upper lateral panel right side	1			
ZP0406	Upper lateral panel left side	1			
ZP0465	Lower guard for hob 90 sintesi	1			
ZP0964	Rear side closing 090 cooker	1			
ZP1051	Sintesi upper right side clamp 62.5 extended	1			
ZP1052	Sintesi upper left side clamp 62.5 extended	1			
ZP1175	Complete spill tray cooker 90 4 burners/barbecue	1			
ZP1184	Rear bracket for 7-pole terminal block	1			
ZP1243	Rear guard for hob 90 GNS	1			
ZP1417	Ramp hole closing plate	1			
ZP1627	Cover terminal borad 7 P Ascot Genesi	1			
ZP1811	Ramp hole closing plate	2			
ZS0511	Cast-iron grid 2 burners Sintesi	2			
ZS0553	Fry-top/barbecue stainless steel covering	1			
ZS0565	Cast-iron grid for wok	1			
ZS0580	Fry-top cast-iron griddle	1			
ZS0803	Commutator support 2 positions top 90	1			
ZS0820	Barbecue cast-iron griddle support	1			
ZS1059	Heating element barbecue 1200/230 th.7	2			
ZS1076	Energy regulator 230 V EGO EU	2			
ZS1204	Transparent lens	2			
ZS1205	Fluorescent green warning light	2			
ZS1667	Protection frame for barbecue griddle	1			
ZS3047	Knob 58 for built-in oven SLT	6			



Piano genesis GQ9-4T SS OT Steel G20/20 230/50 EU

CLIENTE

Code	Description	Qty	Code	Description	Qty
400689	Gasket gas inlet	3	ZS8633	Plate Wok burner external	1
410610	Pipe holder (G20)IT	1	ZS8634	Spring fixing spark plug for Wok	1
410645	Pipe holder (G30)	1	ZS8638	Wok burner flame spreader BRASS	1
414121	Semi-rapid burner body G20 0,97	1	ZS8684	Plate rapid burner HE2	1
414123	Auxiliary burner body G20 0,72	1	ZS8685	Plate semi-rapid burner HE2	1
414212	Rapid burner body G20 1,15	1	ZS8686	Plate auxiliary burner HE2	1
421323	Gas taps fixing bridle M60	4			
481787	Ignition system 4 flames	1			
601229	Spring fixing spark plug for triple ring P-4	3			
ZA1053	Plate central Wok burner	1			
ZA1141	Ramp 4 burners top 090 GNS	1			
ZP1244	Rear ramp fixing support cooker 70/90/120	1			
ZP1995	Ramp support H17	2			
ZS0813	Micro catenary for 4 burners	1			
ZS0907	Fixing nut for themocouple	3			
ZS2064	Burner spark plug sbf L=900	3			
ZS2217	Gasket for auxiliary burner	1			
ZS2218	Gasket for semi-rapid burner	1			
ZS2219	Gasket for rapid burner	1			
ZS2220	Gasket for triple ring burner	1			
ZS2923	Valved tap for auxiliary burner (bypass 0,27)	1			
ZS2924	Valved tap for rapid/fish-kettle burner	1			
ZS2925	Valved tap for semi-rapid burner	1			
ZS2926	Valved tap for triple-ring burner	1			
ZS3021	Adapter female-male 1/2 BSP 04	1			
ZS3058	Pipe ramp for front left triple ring burner cooker 90 05	2			
ZS3059	Pipe ramp for rear left semi-rapid burner cooker 90 05	2			
ZS4181	Thermocouple SBF L=750 TC	1			
ZS4186	Fixing nut for thermocouple burner 4.5	1			
ZS5272	Thermocouple Cast L=770	3			
ZS6428	Triple ring burner body 3.5 G20 1,28 K	1			
ZS6772	Clamp support for main ramp	5			
ZS8191	Wok burner spark plug sbf DCC M+G INT	1			
ZS8626	Auxiliary burner flame spreader HE2 BRASS	1			
ZS8628	Semi-rapid burner flame spreader HE2 BRASS	1			
ZS8630	Rapid burner flame spreader HE2 BRASS	1			

Piano genesi GQ9-4T SS OT Steel G20/20 230/50 EU (not shown)**CLIENTE**

Code	Description	Qty	Code	Description	Qty
421312	Rapid burner nozzle G30/31 29/37 mbar 0,85	1			
423948	Semi-rapid burner nozzle G30/31 0,65	1			
423951	Auxiliary burner nozzle G30/30 0,50	1			
505241	Screw for tap M4x9	4			
ZS0819	Under knob collars fixing support	2			
ZS0890	Spring for el. controls support	1			
ZS1061	Spring for griddle heating el. support	2			
ZS1176	Wiring diagram for hob S9-4B/T	1			
ZS8645	Pins for Wok	1			
ZS8831	Mega Wok burner nozzle G30/30 0.94	1			

Code	Description	Qty	Code	Description	Qty
414121	Semi-rapid burner body G20 0,97	1			
414123	Auxiliary burner body G20 0,72	1			
414212	Rapid burner body G20 1,15	1			
481787	Ignition system 4 flames	1			
ZA1053	Plate central Wok burner	1			
ZS0580	Fry-top cast-iron griddle	1			
ZS0813	Micro catenary for 4 burners	1			
ZS1059	Heating element barbecue 1200/230 th.7	2			
ZS1076	Energy regulator 230 V EGO EU	2			
ZS1204	Transparent lens	2			
ZS1205	Fluorescent green warning light	2			
ZS2064	Burner spark plug sbf L=900	3			
ZS2217	Gasket for auxiliary burner	1			
ZS2218	Gasket for semi-rapid burner	1			
ZS2219	Gasket for rapid burner	1			
ZS2220	Gasket for triple ring burner	1			
ZS2923	Valved tap for auxiliary burner (bypass 0,27)	1			
ZS2924	Valved tap for rapid/fish-kettle burner	1			
ZS2925	Valved tap for semi-rapid burner	1			
ZS2926	Valved tap for triple-ring burner	1			
ZS4181	Thermocouple SBF L=750 TC	1			
ZS4186	Fixing nut for thermocouple burner 4.5	1			
ZS5272	Thermocouple Cast L=770	3			
ZS6428	Triple ring burner body 3.5 G20 1,28 K	1			
ZS8191	Wok burner spark plug sbf DCC M+G INT	1			
ZS8626	Auxiliary burner flame spreader HE2 BRASS	1			
ZS8628	Semi-rapid burner flame spreader HE2 BRASS	1			
ZS8630	Rapid burner flame spreader HE2 BRASS	1			
ZS8633	Plate Wok burner external	1			
ZS8638	Wok burner flame spreader BRASS	1			
ZS8645	Pins for Wok	1			
ZS8684	Plate rapid burner HE2	1			
ZS8685	Plate semi-rapid burner HE2	1			
ZS8686	Plate auxiliary burner HE2	1			