





Piano genesi GQ9-6W SS OT Steel G20/20 230/50 EU**CLIENTE**

Code	Description	Qty	Code	Description	Qty
ZA0878	Aluminium adhesive badge "Steel tricolore"	1			
ZA1096	Cable clamp	1			
ZA1699	Terminal block for appliance UL	1			
ZC0583	Control panel front 5FI induction Ascot 90 SABBIA with serygr.	1			
ZP0404	Upper lateral panel right side	1			
ZP0406	Upper lateral panel left side	1			
ZP0465	Lower guard for hob 90 sintesi	1			
ZP0964	Rear side closing 090 cooker	1			
ZP1051	Sintesi upper right side clamp 62.5 extended	1			
ZP1052	Sintesi upper left side clamp 62.5 extended	1			
ZP1184	Rear bracket for 7-pole terminal block	1			
ZP1241	Complete spill tray cooker 90 6 burners	1			
ZP1243	Rear guard for hob 90 GNS	1			
ZP1417	Ramp hole closing plate	1			
ZP1627	Cover terminal borad 7 P Ascot Genesi	1			
ZP1811	Ramp hole closing plate	2			
ZS0511	Cast-iron grid 2 burners Sintesi	3			
ZS0565	Cast-iron grid for wok	1			
ZS3047	Knob 58 for built-in oven SLT	6			



Piano genesis GQ9-6W SS OT Steel G20/20 230/50 EU

CLIENTE

Code	Description	Qty	Code	Description	Qty
400689	Gasket gas inlet	3	ZS8630	Rapid burner flame spreader HE2 BRASS	1
410610	Pipe holder (G20)IT	1	ZS8633	Plate Wok burner external	2
410645	Pipe holder (G30)	1	ZS8634	Spring fixing spark plug for Wok	2
414121	Semi-rapid burner body G20 0,97	2	ZS8637	Wok burner body G20/20 1,32	2
414123	Auxiliary burner body G20 0,72	1	ZS8638	Wok burner flame spreader BRASS	2
414212	Rapid burner body G20 1,15	1	ZS8684	Plate rapid burner HE2	1
421323	Gas taps fixing bridle M60	6	ZS8685	Plate semi-rapid burner HE2	2
481918	Ignition system 6 flames	1	ZS8686	Plate auxiliary burner HE2	1
601229	Spring fixing spark plug for triple ring P-4	4			
ZA1053	Plate central Wok burner	2			
ZA1130	Ramp 6 burners top 090 GNS	1			
ZP1244	Rear ramp fixing support cooker 70/90/120	1			
ZP1820	Clamp support for ramp GNS 090 top	1			
ZP1995	Ramp support H17	3			
ZP1998	Commutator support 1 positions GNS H17	3			
ZS0578	Ignition switches for six burners' cooker	1			
ZS0907	Fixing nut for themocouple	4			
ZS2064	Burner spark plug sbf L=900	4			
ZS2217	Gasket for auxiliary burner	1			
ZS2218	Gasket for semi-rapid burner	2			
ZS2219	Gasket for rapid burner	1			
ZS2923	Valved tap for auxiliary burner (bypass 0,27)	1			
ZS2924	Valved tap for rapid/fish-kettle burner	1			
ZS2925	Valved tap for semi-rapid burner	2			
ZS2926	Valved tap for triple-ring burner	2			
ZS3021	Adapter female-male 1/2 BSP 04	1			
ZS3058	Pipe ramp for front left triple ring burner cooker 90 05	3			
ZS3059	Pipe ramp for rear left semi-rapid burner cooker 90 05	3			
ZS4181	Thermocouple SBF L=750 TC	2			
ZS4186	Fixing nut for thermocouple burner 4.5	2			
ZS5272	Thermocouple Cast L=770	4			
ZS6772	Clamp support for main ramp	7			
ZS8191	Wok burner spark plug sbf DCC M+G INT	2			
ZS8194	Gasket for wok burner	2			
ZS8626	Auxiliary burner flame spreader HE2 BRASS	1			
ZS8628	Semi-rapid burner flame spreader HE2 BRASS	2			

Piano genesi GQ9-6W SS OT Steel G20/20 230/50 EU (not shown)**CLIENTE**

Code	Description	Qty	Code	Description	Qty
421312	Rapid burner nozzle G30/31 29/37 mbar 0,85	1			
423948	Semi-rapid burner nozzle G30/31 0,65	2			
423951	Auxiliary burner nozzle G30/30 0,50	1			
505241	Screw for tap M4x9	6			
ZS0465	Wiring diagram for hob S9-6 and S9R-6	1			
ZS8635	Screw M4 x 8 wok burner	8			
ZS8645	Pins for Wok	2			
ZS8831	Mega Wok burner nozzle G30/30 0.94	2			

Code	Description	Qty	Code	Description	Qty
414121	Semi-rapid burner body G20 0,97	2			
414123	Auxiliary burner body G20 0,72	1			
414212	Rapid burner body G20 1,15	1			
481918	Ignition system 6 flames	1			
ZA1053	Plate central Wok burner	2			
ZS0578	Ignition switches for six burners' cooker	1			
ZS2064	Burner spark plug sbf L=900	4			
ZS2217	Gasket for auxiliary burner	1			
ZS2218	Gasket for semi-rapid burner	2			
ZS2219	Gasket for rapid burner	1			
ZS2923	Valved tap for auxiliary burner (bypass 0,27)	1			
ZS2924	Valved tap for rapid/fish-kettle burner	1			
ZS2925	Valved tap for semi-rapid burner	2			
ZS2926	Valved tap for triple-ring burner	2			
ZS4181	Thermocouple SBF L=750 TC	2			
ZS4186	Fixing nut for thermocouple burner 4.5	2			
ZS5272	Thermocouple Cast L=770	4			
ZS8191	Wok burner spark plug sbf DCC M+G INT	2			
ZS8194	Gasket for wok burner	2			
ZS8626	Auxiliary burner flame spreader HE2 BRASS	1			
ZS8628	Semi-rapid burner flame spreader HE2 BRASS	2			
ZS8630	Rapid burner flame spreader HE2 BRASS	1			
ZS8633	Plate Wok burner external	2			
ZS8635	Screw M4 x 8 wok burner	8			
ZS8637	Wok burner body G20/20 1,32	2			
ZS8638	Wok burner flame spreader BRASS	2			
ZS8645	Pins for Wok	2			
ZS8684	Plate rapid burner HE2	1			
ZS8685	Plate semi-rapid burner HE2	2			
ZS8686	Plate auxiliary burner HE2	1			