



N° Object	Code	Description	Qty
1048	ZS2130	Door oven handle for oven 60 chromed SLT cooker 100	1
2158	ZS3438	Pivot rotation hood BBQ	2
2195	ZS3492	Washer rotation hood BBQ	2
2353	ZS4212	Support for complete hood BBQ 70	1
2762	ZS4603	Thermometer D50 0-500 T-C	1
2847	ZS4781	Drip tray top BBQ 70	1
3023	GR4744	Assembly complete support drip tray top BBQ	2
2761	ZS4599	Support for front skewers-holder BBQ	2
2837	ZS4744	Guide for drip tray top BBQ	2
3086	ZS5261	Cooking hood no grill inner BBQ right side external	1
3087	ZS5262	Cooking hood no grill inner BBQ left side external	1
3088	ZS5263	Cooking hood no grill inner BBQ right side internal	1
3089	ZS5264	Cooking hood no grill inner BBQ left side internal	1
4212	ZS6013	Cooking hood no grill inner BBQ 70	1
4213	ZS6014	Cooking hood no grill inner BBQ 70 external	1
5081	ZS7940	Thermometer closing plate	1
5564	ZA0073	Gasket for thermometer	1