



N° Object	Code	Description	Qty
1049	ZS2131	Door oven handle for oven 90 chromed SLT cooker 90/120	1
2158	ZS3438	Pivot rotation hood BBQ	2
2159	ZS3439	Support for complete hood BBQ 90	1
2195	ZS3492	Washer rotation hood BBQ	2
2762	ZS4603	Thermometer D50 0-500 T-C	1
2836	ZS4743	Drip tray top BBQ 90	1
3023	GR4744	Assembly complete support drip tray top BBQ	2
2761	ZS4599	Support for front skewers-holder BBQ	2
2837	ZS4744	Guide for drip tray top BBQ	2
3082	ZS5257	Cooking hood no grill inner BBQ 90 external	1
3085	ZS5260	Cooking hood no grill inner BBQ 90	1
3086	ZS5261	Cooking hood no grill inner BBQ right side external	1
3087	ZS5262	Cooking hood no grill inner BBQ left side external	1
3088	ZS5263	Cooking hood no grill inner BBQ right side internal	1
3089	ZS5264	Cooking hood no grill inner BBQ left side internal	1
5081	ZS7940	Thermometer closing plate	1
5564	ZA0073	Gasket for thermometer	1