




N° Object	Code	Description	Qty
1049	ZS2131	Door oven handle for oven 90 chromed SLT cooker 90/120	1
2158	ZS3438	Pivot rotation hood BBQ	2
2159	ZS3439	Support for complete hood BBQ 90	1
2195	ZS3492	Washer rotation hood BBQ	2
2762	ZS4603	Thermometer D50 0-500 T-C	1
2836	ZS4743	Drip tray top BBQ 90	1
3023	GR4744	Assembly complete support drip tray top BBQ	2
2761	ZS4599	Support for front skewers-holder BBQ	2
2837	ZS4744	Guide for drip tray top BBQ	2
3082	ZS5257	Cooking hood no grill inner BBQ 90 external	1
3085	ZS5260	Cooking hood no grill inner BBQ 90	1
3086	ZS5261	Cooking hood no grill inner BBQ right side external	1
3087	ZS5262	Cooking hood no grill inner BBQ left side external	1
3088	ZS5263	Cooking hood no grill inner BBQ right side internal	1
3089	ZS5264	Cooking hood no grill inner BBQ left side internal	1
5081	ZS7940	Thermometer closing plate	1
5564	ZA0073	Gasket for thermometer	1



N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
19	400689	Gasket gas inlet	1	4900	GR4769	Assembly complete control panel BBQ 90	1
997	ZS1645	Bezel for central vitroceramic /grill knob 58, bright chromed	4	2414	ZS4148	Right cap for control panel BBQ	1
1093	410828	Pipe support	1	2415	ZS4149	Left cap for control panel BBQ	1
1766	ZS3155	Knob 58 for gas burners SLT	4				
2139	ZS3390	Two-sided cast-iron griddle for BBQ	1				
2140	ZS3391	Cast-iron open grid for BBQ	3				
2164	ZS3447	Right side combustion area BBQ	1				
2165	ZS3448	Left side combustion area BBQ	1				
2166	ZS3449	Supports for side top BBQ	4				
2168	ZS3451	Side panel top 90 BBQ	2				
2169	ZS3452	Support for taps cooking top BBQ 90	1				
2170	ZS3453	Rear cooktop BBQ 90	1				
2172	ZS3455	Burners deflector top BBQ	3				
2173	ZS3456	Ramp 4 burners cooktop BBQ 90	1				
2174	ZS3457	Burners cooktop BBQ	4				
2178	ZS3467	Burners heat spreader top BBQ	3				
2211	ZS3916	Protection taps cooktop 90 BBQ	1				
2215	ZS3920	Tool for griddle cleaning BBQ	1				
2591	GR4542	Assembly complete drip tray top BBQ 90 Left	1				
2822	GR4737	Assembly complete drip tray top BBQ 90 Right	1				
3218	ZS4750	Rear side combustion area BBQ 90	1				
3219	ZS4751	Front side combustion area BBQ 90	1				
3220	ZS4752	Guide for drip tray top BBQ	4				
3484	ZS5647	"Steel - Stile in cucina" plate	1				
4417	ZS6807	Tap BBQ burner	4				
4418	ZS6808	Thermocouple BBQ L=300 with 2 nuts included	4				
4430	ZS6874	Ramp support for top 90 BBQ	1				
4711	ZS6772	Clamp support for main ramp	1				




N° Object	Code	Description	Qty
2843	ZS4777	BBQ tool hanger	1
3221	ZS4760	Reinforcement side burner top BBQ	1
3224	ZS4767	Support for side top BBQ	2
4054	ZS4762	Side top left BBQ	1




N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
19	400689	Gasket gas inlet	1				
34	414155	Rapid burner body G30 0,85	1				
69	440403	Plate rapid burner	1				
200	ZS0276	Rapid burner flame spreader	1				
797	410645	Pipe holder (G30)	1				
1179	ZS2219	Gasket for rapid burner	1				
1766	ZS3155	Knob 58 for gas burners SLT	1				
2182	ZS3474	Tap triple ring burner BBQ	1				
2183	ZS3475	Cast-iron grid 1 burner BBQ	1				
2187	ZS3480	Support for tap side top triple crown burner BBQ	1				
2188	ZS3481	Support for tap triple crown burner BBQ	1				
2196	ZS3497	Pipe ramp for side top triple ring burner BBQ	1				
2199	ZS3634	Gas taps fixing bridle	1				
2214	ZS3919	Lower guard for lateral burner table BBQ	1				
2221	ZS3954	Pivot M5 holding top	3				
2543	601229	Spring fixing spark plug for triple ring P-4	1				
2562	506037	Screw M3x8 TC s.steel	2				
2584	ZS4501	Protection covering for side top BBQ	1				
2589	ZS4506	Support for 1 burner griddle cooktop BBQ	4				
2592	ZS4549	Hinge reinforcement right covering for side top BBQ	1				
2593	ZS4550	Hinge reinforcement left covering for side top BBQ	1				
2843	ZS4777	BBQ tool hanger	1				
3221	ZS4760	Reinforcement side burner top BBQ	1				
3223	ZS4766	Support for side burner top triple crown BBQ	2				
3262	ZS5270	Burner spark plug Cast	1				
4310	ZS4757	Side top right BBQ	1				
5558	ZA0058	Ramp 1 burner cooktop, BBQ	1				
5749	ZP0050	Ramp hole closing plate	2				





N° Object	Code	Description	Qty
20	401520	Black cap for glass front panel	4
2142	ZS3422	Hinge reinforcement bottle compartement trolley BBQ	1
2150	ZS3430	Rear side trolley BBQ 90	1
2151	ZS3431	Ceiling trolley BBQ	1
2152	ZS3432	Lower trolley BBQ 90	1
2153	ZS3433	Side trolley BBQ	2
2154	ZS3434	Inner panel trolley side BBQ	4
2155	ZS3435	Upper central support for trolley BBQ	1
2156	ZS3436	Front central support for trolley BBQ	1
2179	GR3468	Assembly transversal reinforcement for bottom trolley BBQ 90	2
2180	ZS3469	Tray for gas bottel trolley BBQ 90	1
2197	ZS3632	Fixed wheel BBQ D100	2
2198	ZS3633	Turning wheel BBQ D100	2
2217	ZS3922	H0 steel hinge BBQ base	2



N° Object	Code	Description	Qty
391	ZS0899	Couple legobox rails partial opening	2
817	ZS0458	Drawer right regulation clip	2
818	ZS0459	Drawer left regulation clip	2
1356	ZS2507	Door oven handle for oven 30 chromed SLT	3
2141	ZS3421	Hinge reinforcement door bottle compartement trolley BBQ	1
2143	ZS3423	Counterdoor bottle door right trolley BBQ	1
2210	ZS3871	Rubber BBQ	6
2216	ZS3921	Doors hinge 94° BBQ	2
2275	ZS4086	Door for gas bottle compartment trolley BBQ	1
2276	ZS4087	Door drawer trolley BBQ	2
4164	ZS6681	Drawer lateral side for cooker S.Steel	4
5491	ZS8872	Bottom drawer trolley BBQ	2
5492	ZS8873	Drawer rear side trolley BBQ	2
5504	ZS8874	Counterdoor drawer trolley BBQ	2

N° Object	Code	Description	Qty
130	601156	Tapping screw M10 galvanized	4
1210	ZS5149	Adhesive tape 33 mt x 17h mm x th 0,6 mm (3M 4930)	60
2200	ZS3639	Safety ring 6 UNI 7434-75	1
2205	ZS3753	Tapping screw M5 s.steel	12
2206	ZS3754	Tapping screw M8 galvanized	24
2218	ZS3928	Cotter pin "R-shaped" white wire	4
2927	ZS4298	Washer 5.3 x 15 x 1.2 s.steel	12
4805	ZS7550	Fixing spring for front profile	4
5028	ZS7381	White glass wool for cover BBQ	1
5029	ZS7382	White glass wool for lateral side cover BBQ	2
5088	ZS7974	Instruction booklet BBQ Caddie Swing Green - Steel Multilanguage	1