



**Piano enfasi E9P-6 SS Steel G20/20 230/50 EU**

CLIENTE

<b>Code</b>	<b>Description</b>	<b>Qty</b>	<b>Code</b>	<b>Description</b>	<b>Qty</b>
ZA0807	Bezel ENF / ADG inox	6			
ZP0676	Clamp for support bar taps ramp	2			
ZP0773	Complete spill tray cooker 90 6 burners DCC Prt/Drb	1			
ZP1784	Rear support for induction 5 elements 90 cm	1			
ZS0565	Cast-iron grid for wok	1			
ZS2700	Cast-iron grid 2 burners Prt / Drb	3			
ZS6284	Support bar taps ramp cooker 90	1			
ZS6695	Clamp for support bar taps ramp	2			
ZS7089	Knob gas burners ATG	6			



# Piano enfasi E9P-6 SS Steel G20/20 230/50 EU

CLIENTE

Code	Description	Qty	Code	Description	Qty
400689	Gasket gas inlet	1	ZS8639	Wok burner flame spreader ALU	1
410828	Pipe support	1	ZS8684	Plate rapid burner HE2	2
414121	Semi-rapid burner body G20 0,97	2	ZS8685	Plate semi-rapid burner HE2	2
414123	Auxiliary burner body G20 0,72	1	ZS8686	Plate auxiliary burner HE2	1
414212	Rapid burner body G20 1,15	2			
421323	Gas taps fixing bridle M60	6			
481918	Ignition system 6 flames	1			
601229	Spring fixing spark plug for triple ring P-4	5			
ZA0877	Ramp 6 burners FE cooker 90 Enfasi top	1			
ZS0578	Ignition switches for six burners' cooker	1			
ZS0907	Fixing nut for themocouple	5			
ZS2064	Burner spark plug sbf L=900	5			
ZS2217	Gasket for auxiliary burner	1			
ZS2218	Gasket for semi-rapid burner	2			
ZS2219	Gasket for rapid burner	2			
ZS2704	Pipe ramp for front left rapid burner cooker 90 Party	1			
ZS2705	Pipe ramp for rear left semi-rapid burner cooker 90 Part	1			
ZS2923	Valved tap for auxiliary burner (bypass 0,27)	1			
ZS2924	Valved tap for rapid/fish-kettle burner	2			
ZS2925	Valved tap for semi-rapid burner	2			
ZS2926	Valved tap for triple-ring burner	1			
ZS3064	Pipe ramp for front left triple ring burner cooker 100 05	1			
ZS4181	Thermocouple SBF L=750 TC	1			
ZS4186	Fixing nut for thermocouple burner 4.5	1			
ZS5272	Thermocouple Cast L=770	5			
ZS5778	Ramp fixing support 90/100 Prt / Drb	3			
ZS6772	Clamp support for main ramp	6			
ZS8191	Wok burner spark plug sbf DCC M+G INT	1			
ZS8194	Gasket for wok burner	1			
ZS8625	Auxiliary burner flame spreader HE2 ALU	1			
ZS8627	Semi-rapid burner flame spreader HE2 ALU	2			
ZS8629	Rapid burner flame spreader HE2 ALU	2			
ZS8632	Plate central Wok burner	1			
ZS8633	Plate Wok burner external	1			
ZS8634	Spring fixing spark plug for Wok	1			
ZS8637	Wok burner body G20/20 1,32	1			

**Piano enfasi E9P-6 SS Steel G20/20 230/50 EU (not shown)**

CLIENTE

<b>Code</b>	<b>Description</b>	<b>Qty</b>	<b>Code</b>	<b>Description</b>	<b>Qty</b>
421312	Rapid burner nozzle G30/31 29/37 mbar 0,85	2			
423948	Semi-rapid burner nozzle G30/31 0,65	2			
423951	Auxiliary burner nozzle G30/30 0,50	1			
481913	Terminal block for oven 32 PA 233	1			
505241	Screw for tap M4x9	6			
ZA0809	Thermostat axis extension EGO 47.72018.000	6			
ZP0563	induction box support braket	2			
ZP0564	Blocking plate hob-side Enfasi/Ascot	2			
ZP0671	Lower guard for hob 90	1			
ZP0673	termina box braket	1			
ZP0674	gas ram fixation braket prt	1			
ZS0465	Wiring diagram for hob S9-6 and S9R-6	1			
ZS2704	Pipe ramp for front left rapid burner cooker 90 Party	1			
ZS2705	Pipe ramp for rear left semi-rapid burner cooker 90 Part	2			
ZS7811	Instruction booklet cooker ENF MULTILANGUAGE	1			
ZS8635	Screw M4 x 8 wok burner	4			
ZS8645	Pins for Wok	1			
ZS8831	Mega Wok burner nozzle G30/30 0.94	1			

**Piano enfasi E9P-6 SS Steel G20/20 230/50 EU (Recommended)**

CLIENTE

Code	Description	Qty	Code	Description	Qty
410828	Pipe support	1			
414121	Semi-rapid burner body G20 0,97	2			
414123	Auxiliary burner body G20 0,72	1			
414212	Rapid burner body G20 1,15	2			
481918	Ignition system 6 flames	1			
ZA0809	Thermostat axis extension EGO 47.72018.000	6			
ZS0578	Ignition switches for six burners' cooker	1			
ZS2064	Burner spark plug sbf L=900	5			
ZS2217	Gasket for auxiliary burner	1			
ZS2218	Gasket for semi-rapid burner	2			
ZS2219	Gasket for rapid burner	2			
ZS2923	Valved tap for auxiliary burner (bypass 0,27)	1			
ZS2924	Valved tap for rapid/fish-kettle burner	2			
ZS2925	Valved tap for semi-rapid burner	2			
ZS2926	Valved tap for triple-ring burner	1			
ZS4181	Thermocouple SBF L=750 TC	1			
ZS4186	Fixing nut for thermocouple burner 4.5	1			
ZS5272	Thermocouple Cast L=770	5			
ZS8191	Wok burner spark plug sbf DCC M+G INT	1			
ZS8194	Gasket for wok burner	1			
ZS8625	Auxiliary burner flame spreader HE2 ALU	1			
ZS8627	Semi-rapid burner flame spreader HE2 ALU	2			
ZS8629	Rapid burner flame spreader HE2 ALU	2			
ZS8632	Plate central Wok burner	1			
ZS8633	Plate Wok burner external	1			
ZS8635	Screw M4 x 8 wok burner	4			
ZS8637	Wok burner body G20/20 1,32	1			
ZS8639	Wok burner flame spreader ALU	1			
ZS8645	Pins for Wok	1			
ZS8684	Plate rapid burner HE2	2			
ZS8685	Plate semi-rapid burner HE2	2			
ZS8686	Plate auxiliary burner HE2	1			