




# Nuovi componenti Serie Q | New components Q Series







| N° Object | Code   | Description                                                         | Qty |
|-----------|--------|---------------------------------------------------------------------|-----|
| 684       | ZS1864 | Support for lateral cast-iron grid cooktop 100                      | 4   |
| 731       | ZS0565 | Cast-iron grid for wok                                              | 1   |
| 1014      | ZS2026 | Thermostat TY60 N.O. fixing B                                       | 1   |
| 1441      | ZS2665 | Support for fan timelag device                                      | 1   |
| 1575      | ZS2931 | Spacer between glasses                                              | 2   |
| 1957      | ZS3495 | Washer 4.3 x 10 x 3                                                 | 4   |
| 2000      | ZS3185 | Back splash for cooker 100 Ascot                                    | 1   |
| 2052      | ZS3643 | Support for internal support control panel 100 Ascot                | 1   |
| 2256      | ZS4056 | Control panel front 5/6 burners M Ascot 100 DC S.STEEL with serygr. | 1   |
| 3031      | ZS4390 | Cast-iron grid 1 burner Ascot 07                                    | 1   |
| 3032      | ZS4391 | Cast-iron grid 2 burners Ascot 07                                   | 2   |
| 3216      | ZS4393 | Cast-iron grid for lateral cooktop 100 Ascot 07                     | 2   |
| 5036      | ZS7681 | Complete upper right side Ascot                                     | 1   |
| 5037      | ZS7682 | Complete upper left side Ascot                                      | 1   |
| 5062      | ZS7866 | Complete spill tray cooker 100 4 burners, Mega Wok Ascot            | 1   |
| 5190      | ZS8174 | Handle for hob cooker Ascot 100 chromed terminal nickel             | 1   |
| 6154      | ZC0334 | Profile control panel drawer 100 Ascot internal black               | 1   |
| 6308      | ZP0412 | Profile control panel drawer 100 Ascot external inox                | 1   |



| N° Object | Code   | Description                                               | Qty | N° Object | Code   | Description                                  | Qty |
|-----------|--------|-----------------------------------------------------------|-----|-----------|--------|----------------------------------------------|-----|
| 19        | 400689 | Gasket gas inlet                                          | 3   | 2543      | 601229 | Spring fixing spark plug for triple ring P-4 | 3   |
| 31        | 414121 | Semi-rapid burner body G20 0,97                           | 1   | 2544      | ZS4186 | Fixing nut for thermocouple burner 4.5       | 1   |
| 32        | 414123 | Auxiliary burner body G20 0,72                            | 1   | 2562      | 506037 | Screw M3x8 TC s.steel                        | 6   |
| 40        | 414212 | Rapid burner body G20 1,15                                | 1   | 2563      | ZS0907 | Fixing nut for themocouple                   | 3   |
| 47        | 421312 | Rapid burner nozzle G30/31 29/37 mbar 0,85                | 1   | 2575      | 505241 | Screw M4                                     | 4   |
| 48        | 421323 | Gas taps fixing bridle M60                                | 4   | 3262      | ZS5270 | Burner spark plug Cast                       | 3   |
| 50        | 423948 | Semi-rapid burner nozzle G30/31 0,65                      | 1   | 3264      | ZS5272 | Thermocouple Cast L=770                      | 3   |
| 52        | 423951 | Auxiliary burner nozzle G30/30 0,50                       | 1   | 3330      | ZS5412 | Ascot chromed knob                           | 4   |
| 99        | 481918 | Ignition system 6 flames                                  | 1   | 4711      | ZS6772 | Clamp support for main ramp                  | 5   |
| 293       | ZS0578 | Ignition switches for six burners' cooker                 | 1   | 5201      | ZS8191 | Wok burner spark plug sbf DCC M+G INT        | 1   |
| 796       | 410610 | Pipe holder (G20)IT                                       | 1   | 5203      | ZS8193 | Plate central Wok burner                     | 1   |
| 797       | 410645 | Pipe holder (G30)                                         | 1   | 5204      | ZS8194 | Gasket for wok burner                        | 1   |
| 1177      | ZS2217 | Gasket for auxiliary burner                               | 1   | 5364      | ZS8626 | Auxiliary burner flame spreader HE2 BRASS    | 1   |
| 1178      | ZS2218 | Gasket for semi-rapid burner                              | 1   | 5365      | ZS8628 | Semi-rapid burner flame spreader HE2 BRASS   | 1   |
| 1179      | ZS2219 | Gasket for rapid burner                                   | 1   | 5366      | ZS8630 | Rapid burner flame spreader HE2 BRASS        | 1   |
| 1567      | ZS2923 | Valved tap for auxiliary burner (bypass 0,27)             | 1   | 5368      | ZS8633 | Plate Wok burner external                    | 1   |
| 1568      | ZS2924 | Valved tap for rapid/fish-kettle burner                   | 1   | 5369      | ZS8634 | Spring fixing spark plug for Wok             | 1   |
| 1569      | ZS2925 | Valved tap for semi-rapid burner                          | 1   | 5370      | ZS8635 | Screw M4 wok burner                          | 4   |
| 1570      | ZS2926 | Valved tap for triple-ring burner                         | 1   | 5371      | ZS8637 | Wok burner body G20/20 1,32                  | 1   |
| 1589      | ZS2932 | Ramp 6 burners cooker 090/100 double oven 06              | 1   | 5372      | ZS8638 | Wok burner flame spreader BRASS              | 1   |
| 1591      | ZS2934 | Rear ramp fixing support cooker 70 / 100 TC / DC          | 1   | 5401      | ZS8684 | Plate rapid burner HE2                       | 1   |
| 1632      | ZS3021 | Adapter female-male 1/2 BSP 04                            | 1   | 5402      | ZS8685 | Plate semi-rapid burner HE2                  | 1   |
| 1643      | ZS3064 | Pipe ramp for front left triple ring burner cooker 100 05 | 1   | 5403      | ZS8686 | Plate auxiliary burner HE2                   | 1   |
| 1644      | ZS3065 | Pipe ramp for rear left semi-rapid burner cooker 100 05   | 1   | 5454      | ZS8831 | Mega Wok burner nozzle G30/30 0.94           | 1   |
| 1645      | ZS3066 | Pipe ramp for front right auxiliary burner cooker 100 05  | 1   | 5823      | ZS8645 | Pins for Wok                                 | 1   |
| 1646      | ZS3067 | Pipe ramp for rear right rapid burner cooker 100 05       | 1   |           |        |                                              |     |
| 2068      | ZS3791 | Ramp fixing support Ascot /XXL                            | 2   |           |        |                                              |     |
| 2335      | ZS4181 | Thermocouple SBF L=750 TC                                 | 1   |           |        |                                              |     |




| N° Object | Code   | Description                                             | Qty |
|-----------|--------|---------------------------------------------------------|-----|
| 48        | 421323 | Gas taps fixing bridle M60                              | 2   |
| 1567      | ZS2923 | Valved tap for auxiliary burner (bypass 0,27)           | 1   |
| 2335      | ZS4181 | Thermocouple SBF L=750 TC                               | 1   |
| 2543      | 601229 | Spring fixing spark plug for triple ring P-4            | 1   |
| 2544      | ZS4186 | Fixing nut for thermocouple burner 4.5                  | 1   |
| 2563      | ZS0907 | Fixing nut for themocouple                              | 1   |
| 2575      | 505241 | Screw M4                                                | 2   |
| 3330      | ZS5412 | Ascot chromed knob                                      | 2   |
| 3742      | ZS4837 | Pipe ramp for t.c. 4.5 external burner cooker           | 1   |
| 3791      | ZS6109 | Valved tap for triple-ring burner                       | 1   |
| 5199      | ZS8189 | Mega Wok burner body G20/20 0,68 1.40                   | 1   |
| 5200      | ZS8190 | Mega Wok burner flame spreader BRASS                    | 1   |
| 5201      | ZS8191 | Wok burner spark plug sbf DCC M+G INT                   | 1   |
| 5202      | ZS8192 | Plate Mega Wok burner external                          | 1   |
| 5203      | ZS8193 | Plate central Wok burner                                | 1   |
| 5204      | ZS8194 | Gasket for wok burner                                   | 1   |
| 5206      | ZS8197 | Mega Wok burner spark plug sbf DCC G EXT                | 1   |
| 5207      | ZS8198 | Thermocouple SBF L=750 DCC                              | 1   |
| 5208      | ZS8199 | Support for thermocouple DCC                            | 1   |
| 5209      | ZS8200 | Screw M3.5x6                                            | 1   |
| 5369      | ZS8634 | Spring fixing spark plug for Wok                        | 1   |
| 5370      | ZS8635 | Screw M4 wok burner                                     | 4   |
| 5454      | ZS8831 | Mega Wok burner nozzle G30/30 0.94                      | 1   |
| 5460      | ZS8837 | Mega Wok burner nozzle G30/30 0.44                      | 1   |
| 5522      | ZS8980 | Gasket for Mega wok thermocouple support                | 1   |
| 5916      | ZA0275 | Pipe ramp for t.c. 4.5 central burner cooker DCC 90/120 | 1   |






| N° Object | Code   | Description                                       | Qty |
|-----------|--------|---------------------------------------------------|-----|
| 94        | 481814 | Commutator multif. for 90 built-in oven(no pizza) | 1   |
| 107       | 482120 | Thermostat cooker 192                             | 1   |
| 455       | ZS1075 | Oven thermostat                                   | 1   |
| 538       | ZS1204 | Led transparent                                   | 3   |
| 539       | ZS1205 | Fluorescent green warning light                   | 1   |
| 823       | ZS1755 | Fluorescent orange warning light                  | 2   |
| 2016      | ZS3227 | Commutator support 3 positions                    | 1   |
| 2067      | ZS3785 | Knob for timer gray                               | 5   |
| 3330      | ZS5412 | Ascot chromed knob                                | 3   |
| 3922      | ZS6184 | Timer (white led) LCD-ELA 1000                    | 1   |
| 4137      | ZS6655 | Steam oven functions switch                       | 1   |
| 4636      | ZS7248 | Bezel for function oven                           | 1   |
| 5074      | ZS7893 | Commutator oven functions 060 R                   | 1   |




| N° Object | Code   | Description                                                                | Qty | N° Object | Code   | Description                                                   | Qty |
|-----------|--------|----------------------------------------------------------------------------|-----|-----------|--------|---------------------------------------------------------------|-----|
| 20        | 401520 | Black cap for glass front panel                                            | 2   | 4157      | ZS6628 | Bracket condensate collection for 100 DC Steam                | 1   |
| 98        | 481913 | Terminal block for oven 32 PA 233                                          | 1   | 4166      | ZS6683 | Drawer upper guard for cooker 100 double oven Steam           | 1   |
| 123       | 541011 | Spacer washer for built-in oven                                            | 2   | 4167      | ZS6684 | Spacer for drawer guide                                       | 2   |
| 392       | ZS0903 | Sintesi black foot H.15                                                    | 4   | 4168      | ZS6685 | Reinforcement for ceiling drawer cooker 100 SF double oven 04 | 1   |
| 1294      | ZS2440 | Air conveyor for cooktop 100 DC double oven 04                             | 1   | 4169      | ZS6686 | Muffle fan guard cooker 100 double/Triple oven Steam          | 1   |
| 1316      | ZS2474 | Front central muffle support cooker 100/120 double oven                    | 1   |           |        |                                                               |     |
| 1317      | ZS2475 | Front support for muffle left/right side 100/120 double/triple oven cooker | 2   |           |        |                                                               |     |
| 1318      | ZS2477 | Rear support for muffle left/right side cooker 100 double/triple oven      | 2   |           |        |                                                               |     |
| 1345      | ZS2479 | Lower guard for cooker 100 double oven 04                                  | 1   |           |        |                                                               |     |
| 1414      | ZS2601 | Terminal board support                                                     | 1   |           |        |                                                               |     |
| 1439      | ZS2663 | Cooling fan L=180 Plaset (AU)                                              | 1   |           |        |                                                               |     |
| 1440      | ZS2664 | Air conveyor separator cooker 100 DC/TC                                    | 1   |           |        |                                                               |     |
| 1462      | ZS2472 | Reinforcement for ceiling drawer cooker 100 double oven 04                 | 1   |           |        |                                                               |     |
| 1464      | ZS2476 | Rear central support for muffle cooker 100 double oven                     | 1   |           |        |                                                               |     |
| 1465      | ZS2478 | Reinforcement for lower guard cooker 100 double oven 04                    | 2   |           |        |                                                               |     |
| 1575      | ZS2931 | Spacer between glasses                                                     | 1   |           |        |                                                               |     |
| 1595      | ZS2938 | Ramp hole closing plate                                                    | 1   |           |        |                                                               |     |
| 1948      | ZS3225 | Complete lower right/left side Ascot S.STEEL                               | 2   |           |        |                                                               |     |
| 2006      | ZS3198 | Rear guard for cooker 100 double oven Ascot                                | 1   |           |        |                                                               |     |
| 2008      | GR3201 | Assembly support lower left side Ascot                                     | 1   |           |        |                                                               |     |
| 130       | 601156 | Tapping screw M10 galvanized                                               | 2   |           |        |                                                               |     |
| 2026      | ZS3318 | Reinforcement drawer side structure plinth Ascot                           | 1   |           |        |                                                               |     |
| 2010      | ZS3203 | Plinth for cooker 100 double oven Ascot                                    | 1   |           |        |                                                               |     |
| 2013      | ZS3206 | Plinth rear for cooker 100 Ascot                                           | 1   |           |        |                                                               |     |
| 2024      | ZS3305 | Fixing plate for top Ascot                                                 | 2   |           |        |                                                               |     |
| 2025      | GR3317 | Assembly support lower right side Ascot                                    | 1   |           |        |                                                               |     |
| 130       | 601156 | Tapping screw M10 galvanized                                               | 2   |           |        |                                                               |     |
| 2026      | ZS3318 | Reinforcement drawer side structure plinth Ascot                           | 1   |           |        |                                                               |     |


2728



| N° Object | Code   | Description                                                  | Qty |
|-----------|--------|--------------------------------------------------------------|-----|
| 2728      | GR4342 | Assembly glued oven door 60/100 double oven Ascot            | 1   |
| 2937      | GR4313 | Assembly door 30/60/90 right bar profile 07                  | 1   |
| 2938      | GR4314 | Assembly door 30/60/90 left bar profile 07                   | 1   |
| 1334      | ZS2308 | Inner glass oven door 60                                     | 1   |
| 1337      | ZS2393 | In-between glass oven door 60 04                             | 1   |
| 1339      | ZS2416 | Door hinge for multifunction oven 60                         | 2   |
| 1280      | ZS2419 | Spring for door glass assembling 04                          | 6   |
| 1383      | ZS2550 | Glued external oven door 60/100 double oven                  | 1   |
| 2943      | ZS4746 | Right support for inner glass                                | 1   |
| 2944      | ZS4747 | Left support for inner glass                                 | 1   |
| 5193      | ZS8177 | Handle for oven door 60 Ascot 70/100 chromed terminal nickel | 1   |




| N° Object | Code   | Description                                                | Qty | N° Object | Code   | Description                                                | Qty |
|-----------|--------|------------------------------------------------------------|-----|-----------|--------|------------------------------------------------------------|-----|
| 30        | 411213 | Lateral frame support for built-in oven                    | 2   | 4024      | ZS6246 | Grill heating element support for muffle oven 60 S.Steel   | 1   |
| 82        | 481403 | Thermoswitch 16 Ampere                                     | 1   | 4025      | ZS6247 | Fan cover for oven 60 with turnspit hole S.STEEL           | 1   |
| 128       | 601152 | Spring fixing feeler for built-in oven                     | 2   | 4059      | ZS6034 | Oven lateral frame 30/60/90 S.Steel                        | 2   |
| 566       | ZS7590 | Lower heating element for oven 60 (1200W/230V)             | 1   | 4084      | ZS6542 | Complete muffle bottom for oven 60 S.Steel Steam           | 1   |
| 1209      | 414559 | Lateral frame support for built-in oven                    | 6   | 4115      | ZS6631 | Complete Lamp-holder for oven (max 25 W)                   | 1   |
| 1260      | ZS2395 | Hinge support 06                                           | 2   | 4123      | ZS6653 | Carafe graduate 0.5                                        | 1   |
| 1333      | ZS2289 | Support for grillrod 60/90                                 | 1   | 4124      | ZS6654 | Steam flexible pipe                                        | 1   |
| 1349      | ZS2499 | Fixing support for turnspit motor oven 60/90               | 1   | 4132      | ZS6541 | Gasket oven 60 H=8.9 mat HT                                | 1   |
| 1424      | ZS2629 | White glass wool for rear side 60 oven 04                  | 1   | 4162      | ZS6679 | O-ring 3021 viton                                          | 1   |
| 1425      | ZS2632 | White glass wool for 60 oven 04                            | 1   | 4296      | ZS9953 | Lower heating elem.support oven 60                         | 1   |
| 1467      | ZS2604 | Support for safety thermostat 04                           | 1   | 4574      | ZS6005 | Fixing support for turnspit motor oven 60/90               | 1   |
| 1760      | ZS3078 | Telescopic liner left                                      | 1   | 5047      | ZS7807 | Reinforce fan cover for oven 90 with turnspit hole S.STEEL | 1   |
| 1761      | ZS3079 | Telescopic liner right                                     | 1   | 5215      | ZS8228 | Steam generator cover 60                                   | 1   |
| 1832      | 482094 | Grill heating element for oven 60 (1900+850W)              | 1   | 5781      | ZS6558 | Adapter for lower heating elements                         | 1   |
| 2891      | 482589 | Circular heating element 230V-2100W                        | 1   | 6272      | ZA0488 | Circular tangential oven 90 fan without fan and nut        | 1   |
| 3259      | ZS5174 | Turnspit for oven 60 (4 forks + handle) - 04               | 1   | 6273      | ZA0489 | Nut for circular tangential oven                           | 1   |
| 3261      | ZS5236 | Turnspit motor reducer 50/60 Hz                            | 1   | 6274      | ZA0490 | Fan for circular tangential oven                           | 1   |
| 3852      | GR6224 | Assembly rear muffle oven 60 S.Steel TDL                   | 1   |           |        |                                                            |     |
| 1401      | ZS2585 | Tapping screw M5 aluminium                                 | 4   |           |        |                                                            |     |
| 3919      | ZS6002 | Reinforce for fixing support for turnspit motor oven 60/90 | 1   |           |        |                                                            |     |
| 3923      | ZS6193 | Lower heating element tray oven 60 04                      | 1   |           |        |                                                            |     |
| 3937      | ZS6339 | Ceramic tiles for oven                                     | 1   |           |        |                                                            |     |
| 3938      | ZS6340 | S.steel Trivet for oven 60                                 | 1   |           |        |                                                            |     |
| 3940      | ZS6342 | S.steel wire grid for oven 60                              | 2   |           |        |                                                            |     |
| 4012      | ZS6215 | Stainless Steel muffle ceiling oven 60                     | 1   |           |        |                                                            |     |
| 4016      | ZS6219 | S.Steel muffle front side oven 60                          | 1   |           |        |                                                            |     |
| 4019      | ZS6222 | Side muffle oven 30/60/90 S.Steel TDL                      | 2   |           |        |                                                            |     |
| 4022      | ZS7594 | Drip tray for oven 60 S.Steel TDL                          | 1   |           |        |                                                            |     |






| N° Object | Code   | Description                                                   | Qty |
|-----------|--------|---------------------------------------------------------------|-----|
| 2716      | GR4330 | Assembly glued oven door 30 s.steel Ascot                     | 1   |
| 2937      | GR4313 | Assembly door 30/60/90 right bar profile 07                   | 1   |
| 2938      | GR4314 | Assembly door 30/60/90 left bar profile 07                    | 1   |
| 1224      | ZS2311 | Inner glass oven door 30                                      | 1   |
| 1256      | ZS2390 | In-between glass oven door 30 04                              | 1   |
| 1277      | ZS2414 | Door hinge for oven 60 G                                      | 2   |
| 1280      | ZS2419 | Spring for door glass assembling 04                           | 6   |
| 1381      | ZS2546 | Glued external oven door 30 KL                                | 1   |
| 2943      | ZS4746 | Right support for inner glass                                 | 1   |
| 2944      | ZS4747 | Left support for inner glass                                  | 1   |
| 5192      | ZS8176 | Handle for oven door 30 Ascot 100/120 chromed terminal nickel | 1   |



| N° Object | Code   | Description                                                   | Qty | N° Object | Code | Description | Qty |
|-----------|--------|---------------------------------------------------------------|-----|-----------|------|-------------|-----|
| 82        | 481403 | Thermoswitch 16 Ampere                                        | 1   |           |      |             |     |
| 103       | 482072 | Upper heating element cooker                                  | 1   |           |      |             |     |
| 123       | 541011 | Spacer washer for built-in oven                               | 2   |           |      |             |     |
| 128       | 601152 | Spring fixing feeler for built-in oven                        | 2   |           |      |             |     |
| 188       | ZS7653 | Lower heating element for oven 30                             | 1   |           |      |             |     |
| 1209      | 414559 | Lateral frame support for built-in oven                       | 6   |           |      |             |     |
| 1217      | ZS2283 | Oven lateral frame 30/60/90                                   | 2   |           |      |             |     |
| 1220      | ZS2287 | Chromed wire grid for oven 30                                 | 1   |           |      |             |     |
| 1225      | ZS2312 | Side muffle oven 30/60/90 enamelled 04                        | 2   |           |      |             |     |
| 1226      | ZS2314 | Enamelled muffle ceiling oven 30                              | 1   |           |      |             |     |
| 1227      | ZS2316 | Enamelled muffle bottom for oven 30                           | 1   |           |      |             |     |
| 1228      | ZS2318 | Muffle rear side oven 30 enamelled 04                         | 1   |           |      |             |     |
| 1229      | ZS2320 | Enamelled muffle front side oven 30                           | 1   |           |      |             |     |
| 1247      | ZS2362 | Enamelled drip tray for oven 30                               | 1   |           |      |             |     |
| 1260      | ZS2395 | Hinge support 06                                              | 2   |           |      |             |     |
| 1303      | ZS2454 | Lower heating elem.support oven 30 04                         | 1   |           |      |             |     |
| 1304      | ZS2455 | Lower heating element tray oven 30 04                         | 1   |           |      |             |     |
| 1319      | ZS2488 | Trivet for oven 30 04                                         | 1   |           |      |             |     |
| 1324      | ZS2494 | Grill heating element support for muffle oven 30 enamelled 04 | 1   |           |      |             |     |
| 1413      | ZS2599 | Gasket oven 30 04                                             | 1   |           |      |             |     |
| 1422      | ZS2627 | White glass wool for rear side 30 oven 04                     | 1   |           |      |             |     |
| 1423      | ZS2628 | White glass wool for 30 oven 04                               | 1   |           |      |             |     |
| 1467      | ZS2604 | Support for safety thermostat 04                              | 1   |           |      |             |     |
| 1760      | ZS3078 | Telescopic liner left                                         | 1   |           |      |             |     |
| 1761      | ZS3079 | Telescopic liner right                                        | 1   |           |      |             |     |
| 4115      | ZS6631 | Complete Lamp-holder for oven (max 25 W)                      | 1   |           |      |             |     |
| 5932      | ZP0119 | Turnspit hole cap                                             | 1   |           |      |             |     |



| N° Object | Code   | Description                                         | Qty |
|-----------|--------|-----------------------------------------------------|-----|
| 817       | ZS0458 | Drawer right regulation clip                        | 1   |
| 818       | ZS0459 | Drawer left regulation clip                         | 1   |
| 3484      | ZS5647 | "Steel - Stile in cucina" plate                     | 1   |
| 4062      | ZS6372 | Couple legobox rails partial opening push pull      | 1   |
| 4163      | ZS6680 | Bottom drawer for cooker 100 double oven S.Steel    | 1   |
| 4164      | ZS6681 | Drawer lateral side for cooker S.Steel              | 2   |
| 4165      | ZS6682 | Drawer rear side for cooker 100 double oven S.Steel | 1   |
| 4330      | ZS6840 | Drawer door cooker 100 DC SF S.Steel                | 1   |
| 4332      | ZS6870 | Counterdoor drawer cooker 100 DC SF                 | 1   |

| N° Object | Code   | Description                                  | Qty |
|-----------|--------|----------------------------------------------|-----|
| 132       | ZS5148 | Adhesive tape 16,5 m x 19h (3M)              | 80  |
| 725       | 601108 | Anti-overturning device                      | 0,3 |
| 1586      | ZS2770 | Additional wiring generic L=75 cm Fem Fem    | 2   |
| 2205      | ZS3753 | Tapping screw M5 s.steel                     | 2   |
| 2296      | ZS2666 | Wiring commutators L=20 cm                   | 4   |
| 2307      | ZS3763 | Wiring leds Party                            | 1   |
| 4254      | ZS6759 | Wiring diagram for cooker S10SF-6            | 1   |
| 5050      | ZS7813 | Instruction booklet Top/Cooker Multilanguage | 1   |
| 5212      | ZS8219 | Aluminium adhesive badge "CombiSteam"        | 1   |
| 5357      | ZS8592 | Instruction booklet Combi Steam oven Steel   | 1   |