




# Nuovi componenti Serie Q | New components Q Series






| N° Object | Code   | Description                                        | Qty |
|-----------|--------|----------------------------------------------------|-----|
| 259       | ZS0497 | Cast-iron grid 2 burners Sintesi for cooker 70     | 2   |
| 731       | ZS0565 | Cast-iron grid for wok                             | 1   |
| 1014      | ZS2026 | Thermostat TY60 N.O. fixing B                      | 1   |
| 1023      | ZS2093 | Sintesi upper right side clamp 62.5 extended       | 1   |
| 1024      | ZS2094 | Sintesi upper left side clamp 62.5 extended        | 1   |
| 1061      | ZS2163 | Blocking device for frontal bar profile top SLT    | 2   |
| 1208      | GR2282 | Assembly frontal bar profile top 70 polished       | 1   |
| 1612      | ZS3020 | Support for connection top-base                    | 2   |
| 1667      | ZS3012 | Upper lateral panel right side                     | 1   |
| 1668      | ZS3014 | Upper lateral panel left side                      | 1   |
| 4987      | GR8715 | Assembly cooktop cooker 70 4 burners DCC           | 1   |
| 1441      | ZS2665 | Support for fan timelag device                     | 1   |
| 5503      | ZS6140 | Display support                                    | 1   |
| 5779      | ZS6134 | Support for back splash h. 4 cm cooker 090 Sintesi | 1   |
| 5843      | ZS8868 | Support for back splash h. 4 cm cooker 090 Sintesi | 1   |




| N° Object | Code   | Description                                               | Qty | N° Object | Code   | Description                                                     | Qty |
|-----------|--------|-----------------------------------------------------------|-----|-----------|--------|-----------------------------------------------------------------|-----|
| 19        | 400689 | Gasket gas inlet                                          | 3   | 1647      | ZS3068 | Pipe ramp for rear central triple ring burner for cooker 100 05 | 1   |
| 31        | 414121 | Semi-rapid burner body G20 0,97                           | 1   | 1648      | ZS3069 | Pipe ramp for front central semi-rapid burner for cooker 100 05 | 1   |
| 32        | 414123 | Auxiliary burner body G20 0,72                            | 1   | 1766      | ZS3155 | Knob 58 for gas burners SLT                                     | 4   |
| 40        | 414212 | Rapid burner body G20 1,15                                | 1   | 1797      | ZS3369 | Ramp 4 burners cooker 070 extended 62,5 06                      | 1   |
| 47        | 421312 | Rapid burner nozzle G30/31 29/37 mbar 0,85                | 1   | 2335      | ZS4181 | Thermocouple SBF L=600 t.c.4.5                                  | 1   |
| 48        | 421323 | Gas taps fixing bridle M60                                | 4   | 2543      | 601229 | Spring fixing spark plug for triple ring P-4                    | 1   |
| 50        | 423948 | Semi-rapid burner nozzle G30/31 0,65                      | 1   | 2544      | ZS4186 | Fixing nut for thermocouple burner 4.5                          | 1   |
| 52        | 423951 | Auxiliary burner nozzle G30/30 0,50                       | 1   | 2562      | 506037 | Screw M3x8 TC s.steel                                           | 6   |
| 93        | 481787 | Ignition system 4 flames                                  | 1   | 2563      | ZS0907 | Fixing nut for themocouple                                      | 3   |
| 265       | ZS0504 | Ramp fixing support                                       | 2   | 2575      | 505241 | Screw M4                                                        | 4   |
| 376       | ZS0813 | Micro catenary for 4 burners                              | 1   | 3262      | ZS5270 | Burner spark plug Cast                                          | 3   |
| 378       | ZS0819 | Under knob collars fixing support                         | 2   | 3264      | ZS5272 | Thermocouple Cast L=770                                         | 3   |
| 796       | 410610 | Pipe holder (G20)IT                                       | 1   | 4010      | ZS6150 | Rear ramp fixing support cooker 100 triple oven                 | 1   |
| 797       | 410645 | Pipe holder (G30)                                         | 1   | 4711      | ZS6772 | Clamp support for main ramp                                     | 5   |
| 998       | ZS1646 | Bezel for front left burner knob 58, bright chromed       | 1   | 5201      | ZS8191 | Wok burner spark plug sbf DCC M+G INT                           | 1   |
| 999       | ZS1647 | Bezel for rear left burner knob 58, bright chromed        | 1   | 5203      | ZS8193 | Plate central Wok burner                                        | 1   |
| 1004      | ZS1652 | Bezel for front right burner knob 58, bright chromed      | 1   | 5204      | ZS8194 | Gasket for wok burner                                           | 1   |
| 1005      | ZS1653 | Bezel for rear right burner knob 58, bright chromed       | 1   | 5364      | ZS8626 | Auxiliary burner flame spreader HE2 BRASS                       | 1   |
| 1177      | ZS2217 | Gasket for auxiliary burner                               | 1   | 5365      | ZS8628 | Semi-rapid burner flame spreader HE2 BRASS                      | 1   |
| 1178      | ZS2218 | Gasket for semi-rapid burner                              | 1   | 5366      | ZS8630 | Rapid burner flame spreader HE2 BRASS                           | 1   |
| 1179      | ZS2219 | Gasket for rapid burner                                   | 1   | 5368      | ZS8633 | Plate Wok burner external                                       | 1   |
| 1567      | ZS2923 | Valved tap for auxiliary burner (bypass 0,27)             | 1   | 5369      | ZS8634 | Spring fixing spark plug for Wok                                | 1   |
| 1568      | ZS2924 | Valved tap for rapid/fish-kettle burner                   | 1   | 5370      | ZS8635 | Screw M4 wok burner                                             | 4   |
| 1569      | ZS2925 | Valved tap for semi-rapid burner                          | 1   | 5371      | ZS8637 | Wok burner body G20/20 1,32                                     | 1   |
| 1570      | ZS2926 | Valved tap for triple-ring burner                         | 1   | 5372      | ZS8638 | Wok burner flame spreader BRASS                                 | 1   |
| 1632      | ZS3021 | Adapter female-male 1/2 BSP 04                            | 1   | 5401      | ZS8684 | Rapid spreader cap HE2                                          | 1   |
| 1643      | ZS3064 | Pipe ramp for front left triple ring burner cooker 100 05 | 1   | 5402      | ZS8685 | Semi-rapid spreader cap HE2                                     | 1   |
| 1644      | ZS3065 | Pipe ramp for rear left semi-rapid burner cooker 100 05   | 1   | 5403      | ZS8686 | Auxiliary spreader cap HE2                                      | 1   |

| N° Object | Code   | Description                        | Qty |
|-----------|--------|------------------------------------|-----|
| 5454      | ZS8831 | Mega Wok burner nozzle G30/30 0.94 | 1   |
| 5823      | ZS8645 | Pins for Wok                       | 1   |




| N° Object | Code   | Description                                           | Qty |
|-----------|--------|-------------------------------------------------------|-----|
| 94        | 481814 | Commutator multif. for 90 built-in oven(no pizza)     | 1   |
| 371       | ZS0802 | Commutator support 2 controls                         | 1   |
| 390       | ZS0890 | Spring for el. controls support                       | 1   |
| 455       | ZS1075 | Thermostat for built-in oven                          | 1   |
| 538       | ZS1204 | Led transparent                                       | 2   |
| 539       | ZS1205 | Fluorescent green warning light                       | 1   |
| 708       | ZS1916 | Knob for timer steel-colour 988                       | 6   |
| 740       | ZS1747 | Timer (blue led) 50 Hz                                | 1   |
| 823       | ZS1755 | Fluorescent orange warning light                      | 1   |
| 991       | ZS1639 | Bezel for main oven functions knob 58, bright chromed | 1   |
| 994       | ZS1642 | Bezel for oven temperature knob 58, bright chrome     | 1   |
| 1769      | ZS3158 | Knob 58 for oven temperature SLT                      | 1   |
| 1895      | ZS3652 | Glass lcd 6 button no hole                            | 1   |
| 4137      | ZS6655 | Steam oven functions switch                           | 1   |
| 4229      | ZS6321 | Knob 58 main oven functions SLT                       | 1   |
| 5521      | ZS6139 | Electrical display support                            | 1   |







| N° Object | Code   | Description                                       | Qty |
|-----------|--------|---------------------------------------------------|-----|
| 20        | 401520 | Black cap for glass front panel                   | 1   |
| 98        | 481913 | Terminal board for oven 32 PA 233                 | 1   |
| 123       | 541011 | Spacer washer for built-in oven                   | 4   |
| 300       | GR0591 | Assembly complete lower reinforcement right side  | 1   |
| 130       | 601156 | Tapping screw M10 galvanized                      | 2   |
| 301       | GR0592 | Assembly complete lower reinforcement left side   | 1   |
| 130       | 601156 | Tapping screw M10 galvanized                      | 2   |
| 392       | ZS0903 | Sintesi black foot H.15                           | 4   |
| 1414      | ZS2601 | Terminal board support                            | 1   |
| 1427      | ZS2634 | Air conveyor for cooktop 070/070 double oven      | 1   |
| 1439      | ZS2663 | Cooling fan L=180 Plaset (AU)                     | 1   |
| 1544      | ZS2893 | Lower guard for cooker 070 04                     | 1   |
| 1546      | ZS2895 | Front support for muffle left/right side 70       | 2   |
| 1547      | ZS2896 | Rear support for muffle left/right side cooker 70 | 2   |
| 1595      | ZS2938 | Ramp hole closing plate                           | 1   |
| 1714      | ZS3265 | Plinth for cooker 70                              | 1   |
| 1757      | ZS3016 | Complete lower side panel DX 04                   | 1   |
| 1758      | ZS3018 | Complete lower left side 04                       | 1   |
| 1806      | ZS3381 | Rear guard for cooker 70 extended 62.5 06         | 1   |
| 4167      | ZS6684 | Reinforcement for lower guard oven                | 2   |
| 4643      | ZS6958 | Bracket condensate collection for 070 Steam       | 1   |
| 4645      | ZS7115 | Upper guard for drawer 70                         | 1   |
| 4646      | ZS7117 | Muffle fan guard cooker 070/070 double oven       | 1   |



| N° Object | Code   | Description                                         | Qty |
|-----------|--------|-----------------------------------------------------|-----|
| 2600      | GR2548 | Assembly glued oven door 60/70                      | 1   |
| 2937      | GR4313 | Assembly door 30/60/90 right bar profile 07         | 1   |
| 2938      | GR4314 | Assembly door 30/60/90 left bar profile 07          | 1   |
| 1048      | ZS2130 | Door oven handle for oven 60 chromed SLT cooker 100 | 1   |
| 1334      | ZS2308 | Inner glass oven door 60                            | 1   |
| 1337      | ZS2393 | In-between glass oven door 60 04                    | 1   |
| 1339      | ZS2416 | Door hinge for multifunction oven 60                | 2   |
| 1280      | ZS2419 | Spring for door glass assembling 04                 | 6   |
| 1382      | ZS2548 | Glued external oven door 60/070                     | 1   |
| 2943      | ZS4746 | Right support for inner glass                       | 1   |
| 2944      | ZS4747 | Left support for inner glass                        | 1   |



| N° Object | Code   | Description                                                | Qty | N° Object | Code   | Description                                              | Qty |
|-----------|--------|------------------------------------------------------------|-----|-----------|--------|----------------------------------------------------------|-----|
| 30        | 411213 | Lateral frame support for built-in oven                    | 2   | 4022      | ZS7594 | Drip tray for oven 60 S.Steel TDL                        | 1   |
| 82        | 481403 | Thermoswitch 16 Ampere                                     | 1   | 4024      | ZS6246 | Grill heating element support for muffle oven 60 S.Steel | 1   |
| 89        | 481727 | Circular tangential oven 90 fan (AU) with fan and nut      | 1   | 4025      | ZS6247 | Fan cover for oven 60 with turnspit hole S.STEEL         | 1   |
| 128       | 601152 | Spring fixing feeler for built-in oven                     | 2   | 4059      | ZS6034 | Oven lateral frame 30/60/90 S.Steel                      | 2   |
| 566       | ZS7590 | Lower heating element for oven 60 (1200W/230V)             | 1   | 4084      | ZS6542 | Complete muffle bottom for oven 60 S.Steel Steam         | 1   |
| 1209      | 414559 | Lateral frame support for built-in oven                    | 6   | 4115      | ZS6631 | Compete Lamp-holder for oven (max 25 W)                  | 1   |
| 1260      | ZS2395 | Hinge support 06                                           | 2   | 4123      | ZS6653 | Carafe graduate 0.5                                      | 1   |
| 1333      | ZS2289 | Support for grillrod 60/90                                 | 1   | 4124      | ZS6654 | Steam flexible pipe                                      | 1   |
| 1349      | ZS2499 | Fixing support for turnspit motor oven 60/90               | 1   | 4132      | ZS6541 | Gasket oven 60 H=8.9 mat HT                              | 1   |
| 1424      | ZS2629 | White glass wool for rear side 60 oven 04                  | 1   | 4162      | ZS6679 | O-ring 3021 viton                                        | 1   |
| 1425      | ZS2632 | White glass wool for 60 oven 04                            | 1   | 4296      | ZS9953 | Lower heating elem.support oven 60                       | 1   |
| 1467      | ZS2604 | Support for safety thermostat 04                           | 1   | 4574      | ZS6005 | Fixing support for turnspit motor oven 60/90             | 1   |
| 1760      | ZS3078 | Telescopic liner left                                      | 1   | 5047      | ZS7807 | Fan cover for oven 90 with turnspit hole S.STEEL         | 1   |
| 1761      | ZS3079 | Telescopic liner right                                     | 1   | 5215      | ZS8228 | Steam generator cover 90                                 | 1   |
| 1832      | 482094 | Grill heating element for oven 60 (1900+850W)              | 1   | 5781      | ZS6558 | Adapter for lower heating elements                       | 1   |
| 2891      | 482589 | Circular heating element 230V-2100W                        | 1   |           |        |                                                          |     |
| 3259      | ZS5174 | Turnspit for oven 60 (4 forks + handle) - 04               | 1   |           |        |                                                          |     |
| 3261      | ZS5236 | Turnspit motor reducer 50/60 Hz                            | 1   |           |        |                                                          |     |
| 3852      | GR6224 | Assembly rear muffle oven 60/100 S.Steel TDL               | 1   |           |        |                                                          |     |
| 1401      | ZS2585 | Tapping screw M5 aluminium                                 | 4   |           |        |                                                          |     |
| 3919      | ZS6002 | Reinforce for fixing support for turnspit motor oven 60/90 | 1   |           |        |                                                          |     |
| 3923      | ZS6193 | Lower heating element tray oven 60 04                      | 1   |           |        |                                                          |     |
| 3937      | ZS6339 | Ceramic tiles for BBQ                                      | 1   |           |        |                                                          |     |
| 3938      | ZS6340 | S.steel Trivet for oven 60                                 | 1   |           |        |                                                          |     |
| 3940      | ZS6342 | S.steel wire grid for oven 60                              | 2   |           |        |                                                          |     |
| 4012      | ZS6215 | Stainless Steel muffle ceiling oven 60                     | 1   |           |        |                                                          |     |
| 4016      | ZS6219 | S.Steel muffle front side oven 60                          | 1   |           |        |                                                          |     |
| 4019      | ZS6222 | Side muffle oven 30/60/90 S.Steel TDL                      | 2   |           |        |                                                          |     |



| N° Object | Code   | Description                                    | Qty |
|-----------|--------|------------------------------------------------|-----|
| 817       | ZS0458 | Drawer right regulation clip                   | 1   |
| 818       | ZS0459 | Drawer left regulation clip                    | 1   |
| 3484      | ZS5647 | "Steel - Stile in cucina" plate                | 1   |
| 4062      | ZS6372 | Couple legobox rails partial opening push pull | 1   |
| 4164      | ZS6681 | Drawer lateral side for cooker S.Steel         | 2   |
| 4423      | ZS6832 | Counterdoor drawer cooker 070 SF               | 1   |
| 4611      | ZS6833 | Bottom drawer for cooker 070 S.Steel           | 1   |
| 4612      | ZS6834 | Drawer rear side for cooker 070 S.Steel        | 1   |
| 4715      | ZS6831 | Drawer door cooker 070 SF s.steel              | 1   |



| N° Object | Code   | Description                                        | Qty |
|-----------|--------|----------------------------------------------------|-----|
| 132       | ZS5148 | Adhesive tape 16,5 m x 19h (3M)                    | 80  |
| 725       | 601108 | Anti-overturning device                            | 0,3 |
| 1210      | ZS5149 | Adhesive tape 33 mt x 17h mm x th 0,6 mm (3M 4930) | 20  |
| 1586      | ZS2770 | Additional wiring generic L=60 cm Fem Fem          | 2   |
| 2205      | ZS3753 | Tapping screw M5 s.steel                           | 2   |
| 4661      | ZS7307 | Wiring diagram for cooker S7F-4                    | 1   |
| 5050      | ZS7813 | Instruction booklet Top/Cooker Multilanguage       | 1   |
| 5212      | ZS8219 | Aluminium adhesive badge "CombiSteam"              | 1   |
| 5357      | ZS8592 | Instruction booklet Top/Cooker FR                  | 1   |