




N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
129	601154	Timer	1				
1014	ZS2026	Thermostat TY60 N.O. fixing B	2				
1441	ZS2665	Support for fan timelag device	1				
1957	ZS3495	Washer 4.3 x 10 x 3	4				
1996	ZS3171	Blocking plate hob-side Party	2				
3398	ZS5506	Ascot nickel knob	6				
3717	ZS6026	Switch for induction encoder	5				
4210	ZS5377	Energy regulator for induction 230 V EGO EU	5				
4266	ZS6787	Encoders control board	1				
5557	ZA0054	Aluminium adhesive badge "Steel"	1				
5753	ZP0068	Thickness for profile	2				
5763	ZP0082	Commutator support 3 positions	2				
5783	ZS6817	Feet for electronic components EGO	3				
5784	ZS6904	Cover for induction terminal board	1				
5785	ZS6905	Bridge for induction terminal board	1				
5803	ZS8440	Frontal bar profile cooker 90 polished	1				
6071	ZA0469	Induction 5 element OCTA EGO 75.08016.610	1				
6101	GP0211	Assembly cooktop cooker 90 induction Prt/Drb	1				
6069	ZA0467	Glass for 90 induction hob or cooker	1				
6178	ZP0239	Clamp support for induction 90/100 Party lateral	2				
6179	ZP0242	Front support for induction 5 elements 90 cm	1				
6180	ZP0243	Rear support for induction 5 elements 90 cm	1				
6290	ZP0238	Clamp for support bar induction	4				
6302	ZC0367	Back splash for cooker 90 Oxf matt black	1				
6358	ZP0500	Support for electronic control induction element	1				
6363	GP0247	Assembly control panel front 5FI zones induct electric oven OXF 90 Nero serygr.	1				
5801	ZS8317	Display support	1				



N° Object	Code	Description	Qty
94	481814	Commutator multif. for 90 built-in oven(no pizza)	1
455	ZS1075	Oven thermostat	1
538	ZS1204	Led transparent	2
539	ZS1205	Fluorescent green warning light	1
823	ZS1755	Fluorescent orange warning light	1
1588	ZS2889	Commutator oven functions 90 EGO	1
3398	ZS5506	Ascot nickel knob	2
5572	ZA0247	Timer (red led) 1TP ERS watch hands	1
5573	ZA0248	Knob for timer matt Black	1
5771	ZP0132	Electrical display support OXF cook	1
5851	ZS8916	Commutator support 2 positions	1



N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
18	400006	Protection door	2				
98	481913	Terminal block for oven 32 PA 233	1				
392	ZS0903	Sintesi black foot H.15	4				
1439	ZS2663	Cooling fan L=180 Plaset (AU)	2				
1912	ZS2717	Lower guard for cooker 090 Party	1				
1913	ZS2718	Muffle fan guard cooker 90 cm Prt / Drb	1				
3054	ZS5128	Ramp hole closing plate	1				
3484	ZS5647	"Steel - Stile in cucina" plate	1				
5033	ZS7657	Door hinge for drawer door	2				
5267	ZS8339	Upper guard for drawer 90	1				
5268	ZS8340	Front support for muffle left side cooker 90ADG	1				
5269	ZS8341	Front support for muffle right side cooker 90	1				
5270	ZS8342	Rear support for muffle left/right side cooker 90	2				
5271	ZS8343	Rear guard for cooker 90 ADG	1				
5310	ZS8458	Counterdoor drawer cooker 90 ADG	1				
5528	GP0043	Assembly complete lower reinforcement left side	1				
130	601156	Tapping screw M10 galvanized	2				
5745	ZP0033	Plinth lateral left for cooker 90/100 high side OXF	1				
5529	GP0044	Assembly complete lower reinforcement right side	1				
130	601156	Tapping screw M10 galvanized	2				
5746	ZP0034	Plinth lateral right for cooker 90/100 high side OXF	1				
5655	ZC0100	Side external right/left higher Drb / Oxf Nero fumo	2				
5709	ZC0164	Drawer door cooker 090 ADG Nero Fumo	1				
5731	ZC0191	Plinth for cooker 90 Oxf nero fumo	1				
6200	ZP0349	Air conveyor for cooktop SX	1				
6201	ZP0350	Air conveyor for cooktop DX	1				
6220	ZP0435	Air conveyor for cooktop 90	1				



N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
21	401638	Gasket oven 90	1	6272	ZA0488	Circular tangential oven 90 fan without fan and nut	1
82	481403	Thermoswitch 16 Ampere	1	6273	ZA0489	Nut for circular tangential oven	1
84	481589	Grill heating element for oven 90	1	6274	ZA0490	Fan for circular tangential oven	1
128	601152	Spring fixing feeler for built-in oven	2	6276	ZC0303	Grill heating element support for muffle oven 90 enamelled grey	1
720	451200	Chromed wire grid for oven 90 AU	2	6281	ZC0354	Enamelled muffle front side oven 90 grey	1
1209	414559	Lateral frame support for built-in oven	6	6284	ZC0357	Enamelled drip tray for oven 90 grey	1
1217	ZS2283	Oven lateral frame 30/60/90	2				
1260	ZS2395	Hinge support 06	2				
1314	ZS2468	Lower heating elem.support oven 90 04	1				
1315	ZS2469	Lower heating element tray oven 90 04	1				
1321	ZS2490	Trivet for oven 90 04	1				
1328	482325	Circular heating element 230V-2500W	1				
1333	ZS2289	Support for grillrod 60/90	1				
1349	ZS2499	Fixing support for turnspit motor oven 60/90	1				
1420	ZS2625	White glass wool for rear side 90 oven	1				
1421	ZS2626	White glass wool for 90 oven 04	1				
1467	ZS2604	Support for safety thermostat 04	1				
1839	ZS3082	Lower heating element for oven 90 (1400 W)	1				
3260	ZS5175	Turnspit for oven 90 (4 forks + handle) - 04	1				
3261	ZS5236	Turnspit motor reducer 50/60 Hz	1				
4115	ZS6631	Complete Lamp-holder for oven (max 25 W)	2				
4574	ZS6005	Fixing support for turnspit motor oven 60/90	1				
6086	GP0155	Assembly rear muffle oven 90 enamelled grey	1				
1401	ZS2585	Tapping screw M5 aluminium	4				
6128	ZC0296	Side muffle oven 30/60/90 enamelled 04 grey	2				
6129	ZC0297	Enamelled muffle bottom for oven 90 grey	1				
6130	ZC0298	Enamelled muffle ceiling oven 90 grey	1				
6132	ZC0301	Fan cover for oven 90 with turnspit hole grey	1				

6003

1221

4903

5772

5358

5358

2943


4930

2944

3462

5571

5570



N° Object	Code	Description	Qty
6003	GP0076	Assembly glued oven door 90 Oxf	1
4903	GR7666	Assembly door 30/60/90 right bar profile 15	1
4930	GR8097	Assembly door 30/60/90 left bar profile 15	1
5570	ZA0112	Left hinge plate nickel	1
5571	ZA0114	Right hinge plate nickel	1
5772	ZP0141	Glued external oven door 90 Nero Fumo	1
1221	ZS2307	Inner glass oven door 90	1
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1
3462	ZS5609	Handle for oven door 90 Ascot 90/120 nickeled	1
5358	ZS8596	Door hinge for oven 90	2

N° Object	Code	Description	Qty
123	541011	Spacer washer for built-in oven	8
131	BS0296	Adhesive tape 4959	600
132	ZS5148	Adhesive tape 16,5 m x 19h (3M)	120
725	601108	Anti-overturning device	0,3
1210	ZS5149	Adhesive tape 33 mt x 17h mm x th 0,6 mm (3M 4930)	200
1329	ZS5150	Adhesive tape 33 mt x 25h mm x Th 1.55 mm (3M)	10000
1586	ZS2770	Additional wiring generic L=75 cm Fem Fem	2
5793	ZS7811	Instruction booklet cooker Party MULTILANGUAGE	1
6118	ZA0637	Wiring diagram for cooker D9F-6I 2T	1